

**DK 20 HAMMER
OPERATING
&
MAINTENANCE
MANUAL**



1.INTRODUCTION

DKI Valved D.T.H. hammers are robust tools of simple design to provide for maximum Performance with the minimum of maintenance.

DKI Valved hammers are designed to operate efficiently at air pressures, between 100 psi (7 BAR) and 250 psi (17.5 BAR), using a wide range of Button Bit diameters, from 2.75" (70mm) to 3.50" (90mm).


DKI Valved hammers are supplied with a Check Valve arrangement which maintains pressure in the hammer when the air has been shut off, and so helps prevent contaminated water entering the hammer.

DKI Valved hammers are fitted with an Air Metering Plug. This is supplied as a solid plug, but can be drilled out to a selection of hole sizes in order to increase the volume of flushing air, if excess compressed air is available. This is to suit particular drilling conditions.

CONTENT

HAMMERS GENERAL	
<i>Hammer components</i>	
<i>Hammer parts list</i>	
<i>Hammer specifications</i>	
<i>Air consumption figures</i>	
MAINTENANCE OF HAMMERS	
<i>General maintenance</i>	
<i>Wear tolerances</i>	
<i>Selective replacement</i>	
<i>Rebuilding (assembly) of hammer</i>	
LUBRICATION	
<i>Recommended lubricants and rates</i>	
TROUBLESHOOTING	
<i>Problems, causes and remedies</i>	


1. HAMMER COMPONENTS



2. COMPONENT PARTS LIST

REF	DESCRIPTION	PART NO.
1	WEARSLEEVE	HPDK02001
2	TOP SUB	PDK002002
3	TOP SUB O-RING	HPDK02003
4	GUIDE	HPDK02004
5	DISK VALVE	HPDK02005
6	CENTRALIZER	HPDK02006
7	CHECK VALVE	HPDK02007
8	CHOKE SET	HPDK02008
9	C.V SPRING	HPDK02009
10	AIR DISTRIBUTOR	HPDK02010
12	CYLINDER	HPDK02012
14	PISTON	HPDK02014
18	BIT RET RING	HPDK02018
19	BIT RET RING O RING	HPDK02019
20	BIT BEARING	HPDK02020
22	CHUCK	HPDK02022
23	SPACER	HPDK02023
24	CHUCK SEAL	HPDK02024
	Complete Hammer	HABC20-50

3. HAMMER SPECIFICATIONS



Description	Measure	DK-20
Complete weight without bit	kg.	13
	lb.	28.6
Length without bit	mm.	838
	ins	33
Length - bit extended	mm.	889
	ins	35
Length - bit retracted	mm.	889
	ins	35
Outside diameter of hammer	mm.	62
	ins	2.44
Bore diameter	mm.	913
	ins	36
Piston Stroke	mm.	101
	ins	4
Piston Weight	kg.	1
	lb.	4

5. GENERAL MAINTENANCE

In normal dry drilling conditions, it is advisable to dismantle and check all hammer components every 250 hours of operation.


If a part is to be replaced because of irreparable damage or ultimate wear, then that part must be scrapped to ensure it is not put back into further use. This would seriously accelerate wear of certain other components.

1. When new, all DK1 Valved D.T.H. hammers will have a gap between the Chuck and the Wearsleeve. This is necessary to ensure that all the internal components are held securely in place.

This gap will gradually reduce during drilling and it is very important to check this gap approximately every 100 hours of operation.

When this gap reduces to 1.6mm (0.06) it is necessary to install the Backhead spacer. This is to be positioned between the Valve Chest and the Backhead.

To install the Backhead spacer loosen off the Chuck then remove the Backhead and place the Spacer on the Valve Chest. Now torque up the Backhead and tighten up the Chuck. You should now find that the Chuck gap has been restored to its original width.



2. Component checks on dismantled hammer

With the hammer dismantled into its component parts, check for lubrication starvation. The Piston especially will show heat cracks and eventually larger cracks if the hammer has been under lubricated or used with an incorrect type of lubricating oil. (See page 11. For details.)

3. Selective replacement

When the tolerance between the Piston Stem and the Bearing exceeds the values given in the table below, it is necessary to replace the Bearing. Similarly, when the tolerance between the Piston bore and the Valve Seat probe (this is the protuberance over which the Piston head operates), exceeds the limit, the Valve Seat should be replaced.

6. WEAR TOLERANCES

When the Piston and the Inner Cylinder exceed the values shown, either the Piston or the Inner Cylinder must be removed. In this case, do not scrap the replaced part as it can be returned to the hammer when the new partner is installed. In this way it is possible to double the life of both the Piston and the Inner Cylinder.

HAMMER	PISTON INNER CYLINDER	PISTON STEM BEARING	VALVE GUIDE PISTON BORE
DK-20	0.009 ins. (0.23mm)	0.009 ins. (0.23mm)	0.011 ins. (0.28mm)

4. Valves

The DK-20 hammer Disc Valves, which are of even thickness. Check the Valves for cracks or pitting marks. By placing the Disc Valve on the bevelled valve housing and holding it in front of a light (or daylight) it is possible to conduct the 'light test'. That is, if light is discernible between the Valve and Valve Seat, turn it over and test the other side. If light is still discernible scrap the Valve. (*Assuming that the bevelled valve housing is not faulty.*)


5. Check the Valve Guide for score marks. If scored, clean with fine emery cloth.

6. Check the ends of the Cylinder for chipping, also the shoulder of the Bearing. Chipping in these areas indicates that the hammer has been run with the Chuck or Backhead (or both) in a loose condition. Failure to maintain the gap between the Chuck and Wearsleeve will also result in chipping and ultimate failure in the aforementioned areas.

7. Check the Non-return Valve located underneath the Back head. Depress it until it "bottoms" turning it slightly each time to ensure that it does not stick down. It is advisable to change the Check valve if its sealing capacity is in doubt. Check the Spring for breakage or weakness.

9. SELECTIVE REPLACEMENT

1. Mount the Wearsleeve into the vice and nip gently.
2. Push wad of clean rags through the bore.
3. Check bore of Wearsleeve for cleanliness and identify the end of the bore with the two eccentric grooves machined internally. The Split Spacer will be Chuck end fitted to this, the of the Wearsleeve
4. Stand the Wearsleeve, Chuck end uppermost on a wooden block
5. Insert compression tool into the end of the Wearsleeve and place Split Spacer into the compression tool.
6. Drive the Split Spacer through the compression tool, the chamfered end goes in first.
7. When the Split Spacer is clear of compression tool remove tool and drive Split Spacer into the Wearsleeve. Distance from Wearsleeve end face is 3 1/4" (82.55mm) for DK-20
8. Mount the Wearsleeve in the vice with Chuck end to the left.
9. Clean the Bearing and place wide end down on bench.
10. Oil the shank of Piston and stand the Piston inside the Bearing.
11. Clean the Cylinder. Identify the correct way up (*i.e. radiused end to the Bearing*).
12. Lower the Cylinder over the piston until it seats on the bearing shoulder.




13. Valve Assembly

The DK-20 model employ Disc Valves. Clean the Bevelled Valve Housing, the Valve Chest and Centralising Plug. Insert the Plug in its position in the Valve Chest. Clean the Disc Valve and oil it with a light oil. Locate it on the Centralising Plug Join the Valve Chest and Valve Housing with the Disc Valve in place.



10. REASSEMBLY PROCEDURE

14. Oil the guide on the beveled valve housing and the smaller diameter of the valve seat itself. Insert the beveled valve housing into the end of the Cylinder.
15. Smear oil on all outside surfaces of Cylinder, beveled valve housing and bearing.
16. Introduce the assembly to the wearsleeve. The assembly DK-20, will slide comfortably home with the Bearing butting up to the Split Spacer.
17. If a Backhead Spacer is to be fitted, it should be fitted at this stage.
18. Oil the Check Valve and fit into bore of Valve Chest. Push the Check Valve home and check that it does not stick by rotating and fully depressing it to the bottom of the bore in the Valve Chest.
19. Fit a seal to the groove at the base of the Backhead threads grease the threads and screw the Backhead fully home.
20. Fit the plastic thread protector over the Backhead threads.
21. Insert the Bit Retaining ring halves into the Chuck end of the Wearsleeve.
22. Apply grease to threads of Chuck and screw Chuck into Wearsleeve.
23. If a bit is to be fitted slip the Chuck over the Bit splines fit Retainers over plain portion of Bit Shank. Offer the Bit assembly to the Wearsleeve and screw home.
24. Air Metering plug where fitted this is a steel Allen headed type plug which is screwed into the beveled valve housing..



11. LUBRICATION

Inadequate supply of the correct type of oil is a major contributor to excessive Component wear and consequently, a rapid fall off in performance. An air line lubrication should be installed, preferably on the drill rig. This should be of sufficient capacity to supply the required volume of oil for a full shift.

The lubrication must be adjustable and set to ensure the correct flow of oil required by the hammer
The amount of lubricating oil will vary with the operating pressure and volume of air used by the hammer.

As a general guide, any DKI Valved D.T.H. hammer will require 1/3rd of a pint per 100 CFM through the hammer (0.07 ltr. per 1.0 M3/min per hour).

e.g. 4" hammer operating at 150 psi = 300 cfm = 1 pint per hour 10.5 Bar = 8.5 M3/min = 0.6 ltr. per hour

When drilling with foam or water, the amount of lubricating oil should be increased by 50%.

When new drill tubes are put into use, it is recommended that ½ a pint of oil (0.25 ltrs) be poured into each new tube to give them a good coating of oil and to prevent the hammer from running dry at any time. Ambient temperatures will determine the grade of rock drill oil to be used. Should the ambient temperature be between 0°C and 25°C, use a 30 grade oil. When the ambient temperature is over 25°C, use a 50 grade oil.

A selection of recommended rock drill oils suitable for DKI Valved D.T.H. hammers is given below.

MAKE	Type 30 Grade	Type 50 Grade
BP	ENERGOL RD 100	ENERGOL RD300
TEXACO	100/1542 EPM	320/1543 EPM
ESSO	AROX EP 150	AROX EP 320
MOBIL	ALMO 527	ALMO 259
SHELL	TORCULA 100	TELLUS 320

VALVED HAMMER STORAGE PROCEDURE

We recommend following the points listed below when removing a 'Down hole hammer' from service. This will ensure trouble free operation once the hammer starts work again.

- The hammer should be stripped and cleaned and free of all water/moisture as possible.
- DKI 320 or similar rock drill oil should be poured into backhead (see chart below for quantity) allowing all parts to be coated throughout the hammer.
- Both ends of the hammer should be then covered to prevent the ingress of dirt, etc.
- It should be then laid horizontally in a dry environment ready for use next time.

MODEL	QTY in UK Pints	Qty in Liters
DK-20	1/4	0.14

If this procedure is followed then apart from protecting the hammer from corrosion it will protect the parts from premature wear and of course reduce 'down time' and eventual repair costs. However we strongly recommend that the hammer, especially if stored for any long periods of time should be stripped, cleaned, inspected and re-oiled

12. TROUBLE SHOOTING

TROUBLE	PROBABLE CAUSE	REMEDY
Inoperative Drill	Drill bit blow holes blocked	Unblock Holes
	Dirt inside drill	Strip and clean drill
	Worn or damaged parts	Replace damaged parts
	Insufficient lubrication	Check oil level , Adjust lube needle valve
	Excessive lubrication	Adjust lube valve needle
	Hanging piston	Piston stuck, Polish out the score marks
	Insufficient air pressure	Check compressor, discharge and increase to, operational valve
Slow Penetration	Insufficient air pressure	Increase discharge pressure
	Dull drilling bit	Regrind or change bit
	Worn drill parts	Replace worn parts
	Too much or to little lubrication	Check oil level and if necessary adjust lube needle valve
	Dirt in drill	Strip and clean
Low Return Air Velocity	Low air pressure	Increase air pressure
	Insufficient hole clearing air passing through metering plug	Insert metering plug with larger orifice or remove plug altogether
	Drill bit exhaust holes blocked	Clean out blockage
Spasmodic Operation	Flapper valve inserted, wrong way	Turnover Valve
	Failed or damaged parts	Overhaul drill
	Lack of oil	Check lubricator
	Drill bit broken	Replace bit
	Dirt in drill	Strip and clean

13. NOTES